

## Case Cleaning Instructions

### IMPORTANT

Ensure power is turned off & thick gloves are worn to avoid cuts on sharp areas.

### Cleaning Internal Parts

1. Turn off power;
2. Remove products, display plates, grids & food scraps;
3. Check that the fan blades are not running;
4. Wash with warm water and mild detergent/disinfectant/sanitiser;
5. **Keep water away from all electrical parts;**
6. Dry all parts completely;
7. Turn power back on and wait for correct temperature to be reached before loading the case;

### Cleaning External Case

1. Turn off power;
2. Wash all external parts with warm water and mild detergent/disinfectant;
3. Rinse with clean water and thoroughly dry with a soft cloth;

### Warning

- Do not use abrasive products or solvents;
- Do not spray water or detergent on electrical parts;
- Do not use on methacrylate (plexiglass) parts;