

U-ICE MACHINES - WIRING DIAGRAM
 SELF-CONTAINED 1 PHASE

SEE SERIAL PLATE FOR VOLTAGE

CAUTION: DISCONNECT POWER BEFORE WORKING
 ON ELECTRICAL CIRCUITRY.

DIAGRAM SHOWN DURING FREEZE CYCLE

